

Berntsen International, Inc.
Marking the Boundaries of the Nations since 1972

MONUMENT INSTALLATION INSTRUCTIONS

MORASSE SURVEY CAPS FOR REBAR (OPEN CENTER TYPE)

G41, G42, G43, P41, P42, P43, M41, M42, M43, C41, C42, C43

(The Plastic Cap should be installed on the rebar before driving the rebar)

MATERIALS REQUIRED FOR SETTING MONUMENT:

1. Sledgehammer (recommended: Urethane-faced deadblow sledgehammer)
2. Steel stamp set
3. Survey Cap
4. Rebar
5. Work gloves and proper eye protection and clothing

1. Drill a hole in the center of a soft piece of wood. The hole should be 1-1/2 to 2 times the diameter of the rebar you are using. The piece of wood should be a minimum of 6 inches (150mm) square.

2. Put your plastic cap UPSIDE DOWN on the soft piece of wood.

3. Using a hammer, drive the rebar into the socket on the cap until it protrudes about 1/2 inch (13mm) through the cap. This will help insure that when driving your rebar into the ground that there is sufficient distance between the top of the rebar and the surface of the cap to prevent damaging the lettering on the cap.

4. Reverse the cap/rebar assembly and drive into the ground at the desired point. The mushrooming of the top of the rebar will lock the cap onto the rebar.

REMEMBER: "Any Monument Is Only As Good As How It Was Set".

QUESTIONS? PLEASE CONTACT US FOR ASSISTANCE:

Email: surveymark@berntsen.com

Toll-Free Telephone: 1-800-356-7388 (USA, Canada and Caribbean Islands)

Toll-Free Fax: 1-800-249-9794 (USA, Canada and Caribbean Islands)

Telephone: +1 608.249.8549 (all other countries)

Fax: +1 608.249.9794 (all other countries)