

Berntsen International, Inc.
Marking the Boundaries of the Nations since 1972

MONUMENT INSTALLATION INSTRUCTIONS

MODELS A1, A1BR

MATERIALS REQUIRED FOR SETTING MONUMENT:

1. Monument
2. Shovel
3. Post Hole Digger
4. Work gloves and proper eye protection and clothing
5. Steel stamp set
6. Fine-grained washed or play sand
- 7.

****IMPORTANT:** Prior to installation, stamp as much information on the marker as possible.**

INSTALLATION

1. Dig a six-inch diameter hole (using a post hole digger or shovel) to desired depth at installation site - minimum desired depth should be monument length + 1" (25mm).
2. *OPTIONAL STEP:* THROW A SMALL AMOUNT OF DRY CONCRETE MIX INTO BOTTOM OF HOLE (moisture from soil will harden dry concrete mix).
CAUTION: Be careful not to add too much concrete mix - you do not want the mix to go above the break-off portion of the monument (for Model AU-1, see OPTIONAL STEP above).
3. Carefully insert monument into bottom of hole. Rotate monument to fix into soil.
4. **BACKFILL:** Pack soil around monument and tamp thoroughly for positive compaction. (WE RECOMMEND USING A FINE-GRAINED SAND SUCH AS PLAY SAND FOR MAXIMUM COMPACTION AND PROPER DRAINAGE. THIS MATERIAL WILL ALSO PROVIDE A NEUTRAL MATERIAL TO ACT AS A BUFFER BETWEEN THE MONUMENT AND THE SURROUNDING SOIL).
5. You must properly compact all four (4) sides firmly to insure horizontal and vertical stability.

REMEMBER: "Any Monument Is Only As Stable As Its Backfill".

QUESTIONS? PLEASE CONTACT US FOR ASSISTANCE:

Email: surveymark@berntsen.com

Toll-Free Telephone: 1-800-356-7388 (USA, Canada and Caribbean Islands)

Toll-Free Fax: 1-800-249-9794 (USA, Canada and Caribbean Islands)

Telephone: +1 608.249.8549 (all other countries)

Fax: +1 608.249.9794 (all other countries)